


COIL BINDING MACHINE


Punch up to 20 sheets(80g) per time

Manual punch & **Electric** bind


A4 size
Coil 4:1




A



B



C





D

BINDING
MACHINE
Coil 4:1

MANUAL



Punching & Binding



Move margin to adjust paper maring from 2.5mm to 6.5mm.






Move paper size adjuster to center paper to punch.





A4 46 holes punched

Insert paper, pull down handle to punch holes.



Turn on power, and press binding button to make roller moving and binding.




Cut and crimp both ends of the coil with coil crimper.

Finish binding.



Clean waste bin regularly.

Parts of machine



specifications

Punching form	Manual
Binding form	Electric
Max. punch	20 sheets (80g A4 paper)
Max. bind	220 sheets (electric)
Paper size	A4/LTR/B5/A5/etc.(C/D). A4(A/B)
Paper margin	2.5 mm/4.5 mm/6.5 mm
Hole quantity	46pcs
Hole size	Φ 4mm round or 4×5.5mm oval
Hole distance	6.35 mm/6.29mm
Machine size	400×320×180 mm
N.W.	8.5kgs(A)/8KGS(B)/11.5KGS(C)/11KGS(D)

